

How to Punch

A Punch the corners!

- Step 1** Set the guide at **A**
- Step 2** Punch the card by matching it with the guide
- Step 3** Punch the four corners of the card to finish!



B Punch at 180°!

- Step 1** Set the guide at **B**
- Step 2** Push the card to the back, and set at the above mentioned position
- Step 3** Finished!




C You can even punch the corners of a Two-fold Card!

- Step 1** Set the guide at **C**
- Step 2** Punch the card by matching it with the guide



Punch the frame type beautifully!

- Step 1** Use a frame type punch, and punch the four corners of the board in the same manner! **a** **b**
- Step 2** The size of the cards and photos for inside are fine if they are at least 1cm smaller than the dimensions of the board!
- Step 3** Finished!



For the CN30 series, not all the products correspond with **A B C**. Please refer to this part of the individual specifications to check which product fits.

Flora	Correspondence
287016	A B C - No Correspondence

- Step 3** Punch in the same way as "Step 2"
- Step 4** Set the guide at **A** and punch
- Step 3** Finished!



The paper's four corners can be quickly arranged! Three types of arrangement are possible by simply turning the guide.

